

SVERKER 900 Relay and substation test system



- The toolbox for substation 3-phase testing
- Three currents and four voltages
- Stand-alone functionality
- Rugged and reliable for field use
- Generation of 900 V and 105 A in single phase mode
- Secondary and primary testing


DESCRIPTION

The SVERKER 900 Relay and substation test system is the engineer's ultimate toolbox that addresses the increasing need for three-phase testing capability in electrical distribution substations, renewable power generation stations and industrial applications. The intuitive user interface is presented on the LCD touch screen. It has a powerful combination of current and voltage sources and a versatility of measurement possibilities.


The SVERKER 900 is specifically designed for basic, manual three-phase secondary testing of protection devices. In addition, various primary testing can be performed, since the current and voltage sources can be series- and/or parallel connected to allow for up to 105AAC or 900VAC output. All three current and four voltage sources can be individually adjusted with respect to amplitude, phase angle and frequency. The fourth voltage source allows for testing of numerical relays that needs a reference voltage simulating the busbar.

APPLICATION

- Commissioning and maintenance of distributed and generator power Substation
- Protection relays
 - ▶ Electromechanical relays
 - ▶ Static relays
 - ▶ Numerical relays
 - ▶ Self-powered relays
- Plotting current transformer excitation curves
- Current and voltage transformer ratio tests
- Burden measurement for CT circuits
- Polarity (direction) tests
- Impedance measurement
- Primary injection in switchgear
 - ▶ Three phase
 - ▶ Single phase
- Checking SCADA annunciation and measurement values
- Wiring check
- Relays with current transformer-operated trip release unit



All three current generators in parallel.



All four voltage generators in series.

SVERKER 900 Relay and substation test system

PANEL DESCRIPTION


- BINARY INPUTS 1 – 4**
The binary inputs are independently programmable gate circuits that permit simple selection of the desired mode for voltage or contact monitoring operation. Binary input 1 has a selectable threshold voltage.
- EXTRA TIMER**
The timer has separate start and stop inputs, and it can be used to measure both external cycles and sequences initiated by SVERKER. The measured time appears on the display. Each input can be set to respond to the presence or absence of voltage (AC or DC) at a contact.
- BINARY OUTPUT**
The binary output is used to simulate normally open/normally closed contacts for testing breaker failure schemes, or similar power system operations. In addition it may also be used to switch AC/DC voltages and currents.
- A and V**
Current and voltage are measured by the built-in ammeter and voltmeter. Resistance, impedance, phase angle, power and power factor can also be measured. Readings appear on the display. These instruments can also be used to take measurements in external circuits.
- CURRENT GENERATORS**
The current generators can be used separately, in parallel or in series.
The current generators delivers maximum compliance voltage to the load constantly during the test, and range changing is done automatically, on-the-fly, under load.

- VOLTAGE GENERATORS**
The voltage generators can be used separately, in parallel or in series.
- USB**
For external keyboard, mouse, saving test data and for updating internal SW.
- Mains inlet**
- Ground (earth) connection**
- On/Off switch**
- Ethernet port**
For authorized service actions
- Touch screen**
5.7" LCD touch screen
- Control knob**
For setting of current, voltage and other parameter values.

FRONT HMI

The front HMI provide the user with a very simple way to manually or semi-automatic perform the tests, from making a simple primary injection in a switchgear to more complex secondary relay protection testing. The operation is simplified by use of a built-in computer operating system and touch screen.

The front HMI eliminates the need for a computer when testing virtually all types of relay or primary equipment in a substation. Intuitive menu screens and touch screen buttons are provided to quickly and easy select the desired test function. The front HMI includes non-volatile build in data storage for saving tests and test results. By using the USB port, test files/results could be transferred in between the SVERKER 900 and a PC. Test files are saved in csv format for use with Excel[®] to create reports.



All outputs are independent from sudden changes in mains voltage and frequency, and are regulated so changes in load impedance do not affect the output. All current and voltage sources/generators are galvanically separated from each other and from ground. All outputs provide variable frequency.

SVERKER 900 Relay and substation test system

TEST INSTRUMENTS

SVERKER 900 contains a range of test instrument to be used depending of what kind of test to perform. Using the different test instruments you can set the output for the voltage and current generators, but also control them with the control knob.

Main instrument

- Timing test
- Manual determine the pick-up and drop-out of relay contact.
- General: set - inject - measure
- Multiple Timing Test (MTT)
To test and verify currents with different amplitudes applied and to measure corresponding tripping times.
- Continuous current mode
To be used in tests when the current circuit is interrupted repeated times.

CT Magnetization instrument

- Test to determine the knee point voltage of the current transformer.

Prefault – Fault instrument

- Timing test - to be used mainly to test relay which require a simulation of a prefault state before the fault simulation.
- Multiple Timing Test (MTT) with reference curve (IDMT) Inverse Definite Minimum Time.
To test and verify currents with different amplitudes applied and to measure corresponding tripping times.
- Reference curves according to IEC60255-151:2009 "Functional requirements for over/under current protection".

Ramping instrument


- Automatic determine the pickup threshold
- Time testing, e.g. when testing df/dt relays
- Frequency ramp according to IEC 60255-181:2019 "Functional requirements for frequency protection".

Sequence instrument

- Simulation of sequences e.g. auto recloser, motor starts, re-striking earth fault.

Impedance instrument

- The impedance screen allows to test relays directly from the so called impedance plane, where the conversion from the impedance into voltages and currents is automatically done by SVERKER 900.
- Prefault and fault test
- Impedance ramping



MTT in Prefault-Fault instrument with reference curve.

I1	0.000 A	0 °	50.00 Hz
I2	0.000 A	240 °	50.00 Hz
I3	0.000 A	120 °	50.00 Hz
U1	63.00 V	0 °	50.00 Hz
U2	63.00 V	240 °	50.00 Hz
U3	63.00 V	120 °	50.00 Hz

0 VDC BI

TRIP 0.000 s

OFF + TIME ON + TIME

123.45

Ext Timer 0.000 s Voltage 0.001 V AC Current 0.000 A AC

From the Main instrument you easily run the general tests.

I [A]	U [V]
0.037	30.05
0.026	29.21
0.022	28.34
0.018	26.97
0.016	24.88
0.014	21.09

30V 0.2A AUTO

Ext Timer 0.000 s Voltage 0.000 VAC Current 0.000 AAC

Run the CT Magnetization instrument in auto or manual mode.

SVERKER 900 Relay and substation test system

PROTECTIVE RELAY TESTING

SVERKER 900 is performing a wide area for manual secondary testing of protective relay equipment. Virtually all types of single-phase and three-phase protection can be tested, from modern multifunction relays to electromechanical relays. It can inject current up to 105A when high range is needed and it has a frequency range from 10Hz up to 600Hz and also DC could be utilized. In the "expert mode" the user have the possibility to add layers of superimposed frequency. The rugged hardware design is built for field use over a wide temperature range, with intelligent software to perform rapid testing.

APPLICATION EXAMPLE


IMPORTANT!

Read the User's manual before using the instrument.

The connection shows a general configuration that applies to most types of relay testing.

Examples of what SVERKER 900 can test

Examples of what SVERKER 900 can test	ANSI® No.
Distance protection / under impedance relay	21
Overfluxing relays	24
Synchronising or synchronism-check relays	25
Undervoltage relays	27
Directional Power relays	32
Undercurrent or underpower relays	37
Loss of field relays	40
Negative sequence overcurrent relays	46
Phase sequence voltage relays	47
Thermal relays	49
Overcurrent- / ground fault relays	50 (N)
Inverse time overcurrent- / ground fault relays	51 (N)
Power factor relays	55
Overvoltage relays	59
Voltage or current balance relays	60
Directional overcurrent relays / ground fault relay	67 (N)
Motor overload protection	66
DC overcurrent relays	76
Phase-angle measuring or out-of-step protection relays	78
Automatic reclosing devices	79
Frequency relays	81
Carrier or pilot wire	85
Differential protection relays (differential circuits)	87
Directional voltage relays	91
Voltage and power directional relays	92
Tripping relays	94



SVERKER 900

Relay and substation test system

SPECIFICATIONS SVERKER 900

Specifications are valid for resistive load, at 170-240 voltage supply and ambient temperature +25°C ±3°C, (77°F ±5.4°F) after 30 minutes warm up time and in the frequency range 15 Hz to 70 Hz.

All hardware data are for full scale values.

Specifications are subject to change without notice.

Environment

Application field For use in high-voltage substations and industrial environments.

Temperature

Operating 0°C to +50°C (32°F to +122°F)

Storage & transport -40°C to +70°C (-40°F to +158°F)

Humidity 5% – 95% RH, non-condensing

Altitude (operational) 2000 m (6500 ft)

CE-marking

LVD 2014/35/EU

EMC 2014/30/EU

RoHS 2011/65/EU

Classifications and standards

Shock and vibration IEC 60068-2-27

Vibration IEC 60068-2-6

Voltage frequency ramp IEC 60255-181:2019

General

Mains input 100 - 240 V AC, 50 / 60 Hz

Current consumption 10 A (max)

Power consumption 1800 VA (max)

Dimensions

Instrument 350 x 270 x 220 mm (13.8" x 10.6" x 8.7")

Flight case with wheels 615 x 295 x 500 mm (24.2" x 11.6" x 19.7")

Flight case 620 x 295 x 365 mm (24.4" x 11.6" x 14.4")

Weight 15.2 kg (33.5 lbs) Instrument only
29.2 kg (64.4 lbs) with accessories and flight case (with wheels, GD-00185)
24.1 kg (53.1 lbs) with accessories and flight case (GD-00182)

Display 5.7" LCD Touch screen

Available languages Czech, English, French, German, Spanish, Swedish

Measurement section

BINARY INPUTS 1, 2, 3, 4 and EXTERNAL TIMER

Start/Stop

Number 6
Type Dry or wet contacts max, 240VAC or 340VDC

Galvanic Isolation Galvanically separated

Max measuring time 35 minutes

Debounce filter Settable, 0 to 999 ms

BINARY INPUT 1 Adjustable threshold and hysteresis

Timer

Range	Inaccuracy
0 – 50 ms	≤ 1 ms
50 – 500 ms	≤ 2 ms
> 500 ms	≤ 1%

Resolution 1 ms

Voltmeter

Measurement method: AC true RMS, DC mean value

Insulation 900 V, 1273 V_{peak}

Input rating 900 V

Inaccuracy

Ranges DC

0-1 V ±0.5% of reading + 3 mV

0-10 V ±0.5% of reading + 7 mV

0-100 V ±0.5% of reading + 30 mV

0-900 V ±0.5% of reading + 300 mV

Ranges AC

0-1 V ±1% of reading + 5 mV

0-10 V ±1% of reading + 10 mV

0-100 V ±1% of reading + 50 mV

0-900 V ±1% of reading + 300 mV

Resolution

1 mV

Frequency

Range 10 Hz – 600 Hz

Inaccuracy < 0.01%

Resolution < 10 mHz

Ammeter

Measurement method: AC true RMS, DC mean value

Inaccuracy

Ranges DC

0-200 mA ±0.5% of reading + 2 mA

0-1.5 A ±0.5% of reading + 3 mA

0-10 A ±0.5% of reading + 10 mA

Ranges AC

0-200 mA ±1% of reading + 2 mA

0-1.5 A ±1% of reading + 3 mA

0-10 A ±1% of reading + 20 mA

Resolution

0.1 mA

Frequency

Range 10 Hz – 600 Hz

Inaccuracy < 0.01%

Resolution < 10 mHz

Extra measurements

Power factor and phase angle measurements

	Ranges	Resolution	Inaccuracy
Power factor cosφ	-0.01 (cap) to 1 to +0.01 (ind)	< 0.01	<0.04
Phase angle (°) ¹⁾	0° - 360°	<0.1°	<0.8°

Impedance and power measurement

AC Z(Ω), R(Ω), X(Ω), P(W), S(VA), Q(VAR)

DC R(Ω), P(W)

Range Up to 999 kX (X=unit)

1) Valid with current >1 A and voltage >10 V

BINARY OUTPUTS

Insulation 250 V AC

Current 1 A (max)

Voltage 250 V AC or 120 V DC

SVERKER 900

Relay and substation test system

Generation section

Voltage generators

Voltage outputs U1, U2, U3 and U4/DC out
All voltage sources/generators are galvanically separated from each other and from ground.
Floating common return is made by using jumper connectors

Range

4-phase AC	4 x 300 V
4-channel DC	4 x 300 V

Power

4-phase AC	4 x 125 VA (max)
4-channel DC	4 x 125 W (max)

Inaccuracy AC

Typical	0.03% of reading + 0.01% of range
Guaranteed	0.05% of reading + 0.03% of range

Distortion(THD+N)¹⁾

< 0.14% typical (0.25% max)

Resolution

10 mV

Phase

Angle range	0° - 360°
Inaccuracy ²⁾	< 0.5° (at 50-60 Hz)
Resolution	0.1°

Frequency

Range	10 Hz - 600 Hz
Inaccuracy ²⁾	< 0.03 % (45 Hz - 66 Hz)
Resolution	1 mHz

1) THD+N: Values at 50/60 Hz, 200-300 V, ≥1500 Ω load. Measurement band with 22 Hz–22 kHz.

2) The specification is valid for resistive load >2000 Ω for voltage output separately U1, U2, U3 and U4/DC out.

Voltage generators in single-phase mode, AC or DC			
4 Voltage generators in parallel: U1 // U2 // U3 // U4	Voltage	Power (max)	Current (max)
	300 V	375 VA	1.2 A
	100 V	300 VA	3.0 A
	67 V	300 VA	4.5 A
External load: min 7 Ω			
3 Voltage generators in parallel: U1 // U2 // U3	Voltage	Power (max)	Current (max)
	300 V	312 VA	1.0 A
	100 V	250 VA	2.5 A
	67 V	250 VA	3.7 A
External load: min 9 Ω			
4 Voltage generators in series: U1 – U2 – U3 – U4	Voltage	Power (max)	Current (max)
	900 V	450 VA	0.5 A
	400 V	360 VA	0.9 A
	268 V	350 VA	1.3 A
External load: min 100 Ω			
3 Voltage generators in series: U1 – U2 – U3	Voltage	Power (max)	Current (max)
	900 V	350 VA	0.4 A
	300 V	280 VA	0.9 A
	200 V	275 VA	1.4 A
External load: min 75 Ω			

Current generators

Current outputs I1, I2 and I3
All current generators are galvanically separated from each other and from ground
Floating common return, is made by using jumper connectors

Range

3-phase AC	3 x 35 A At least 15 repetitions: 10 s ON and 20 s OFF
------------	---

3-phase DC	3 x 35 A At least 15 repetitions: 10 s ON and 20 s OFF
------------	---

3-phase AC	3 x 20 A continuous
------------	---------------------

3-phase DC	3 x 20 A continuous
------------	---------------------

Power

3-phase AC (max)	3 x 277 VA
------------------	------------

3-phase DC (max)	3 x 275 W
------------------	-----------

Inaccuracy AC

	Range	Error
Typical	<200 mA	<0.5 mA
	200 mA to 35 A	0.1% of reading+0.01% of range
Guaranteed	<200 mA	<3 mA
	200 mA to 35 A	0.4% of reading+0.01% of range

Distortion(THD+N)⁴⁾ < 0.10% typical (0.20% max)

Resolution 1 mA

Compliance voltage ≤50 Vrms

Phase

Angle range	0° - 360°
Inaccuracy ⁵⁾	< 0.2° (50 – 60 Hz)
Resolution	0.1°

Frequency

Range	10 Hz - 600 Hz
Inaccuracy ⁵⁾	< 0.03 % (45 – 66 Hz)
Resolution	1 mHz

4) THD+N: Values at 50/60 Hz, 1-5 A, 0.5 VA load. Measurement band with 22 Hz–22 kHz.

5) The specification is valid for resistive load ≤0.08 Ω and I ≥0.15 A.

Current generators in single-phase mode, AC			
Current generators in parallel: I1 // I2 // I3			
Current	Power (max)	Voltage (max)	Duty cycle
2.6 A	198 VA	76 V	Continuous
16 A	816 VA	51 V	Continuous
26.5 A	827 VA	31.2 V	Continuous
45.5 A	819 VA	18 V	Continuous
60 A	800 VA	14 V	Continuous
105 A	721 VA	7 V	At least 15 repetitions: 10 s ON and 20 s OFF
Current generators in series: I1 – I2 – I3 ⁶⁾			
Current	Power (max)	Voltage (max)	Duty cycle
2.5 A	403 VA	161 V	Continuous
8.2 A	860 VA	105 V	Continuous
17.6 A	827 VA	47 V	Continuous

6) Max 18 A and 200 Hz

SVERKER 900 Relay and substation test system

Optional accessories

Low current adapters LCA1 and LCA2

Dimensions

LCA1	110 x 64 x 28 mm (4.3" x 2.5" x 1.1")
LCA2	110 x 64 x 44 mm (4.3" x 2.5" x 1.7")


Weight (LCA1+LCA2) 0.4 kg (0.9 lbs)

Input 5 A (max)

OPTIONAL ACCESSORIES

SVERKER Viewer

SVERKER Viewer is PC software which can create graphical test reports in pdf format. The pdf test report is created by connecting a PC to SVERKER900 and opening a saved test file from SVERKER900.



Pdf test report from determine the knee point voltage of the current transformer.

Megger Sweden AB	SVERKER Viewer		
Test equipment: Sverker 900	Test file created: 2018-03-19T09:21:12		
Test Report			
Station	Position	Type	Serial no.
SL4.MTT Danderud	+HL77	REX21	557798
All tests			
IL1 > and <>			3/19/2018 9:24:39 AM
Test result			
#	I	Time	
1	1.2 A	3753 ms	
2	1.35 A	2314 ms	
3	1.5 A	1720 ms	
4	1.8 A	1201 ms	
5	2.1 A	885 ms	
6	2.4 A	597 ms	
7	2.6 A	318 ms	
8	3 A	322 ms	
Tested by:	Approved by:		
Date:	Date:		

PDF report from a timing test of overcurrent protection.



Flight case (GD-00182)



Low current adapters (CR-90010)


For generation of low currents (0–30 mA) when testing protection such as sensitive earth fault, capacitor unbalance and reverse power protection.



Calibration Box (CR-91010)

To make a calibration a digital multimeter with high accuracy is also needed, e.g. the Agilent 34410A or equivalent.


INCLUDED ACCESSORIES



Test cable set standard (GA-00030)



Earth (ground) cable (GA-00200)



Cable set, to be used up to 900 V (GA-00036)



Flight case with wheels (GD-00185)



Inside the lid are ten jumpers "parked" in holders, a touch screen, a pen and the quick guide.

ORDERING INFORMATION

Item	Cat. No.
SVERKER 900 Basic	CR-19090
SVERKER 900 Standard	CR-19092
SVERKER 900 Expert	CR-19094

Instrument configuration table

Instrument	Basic	Standard	Expert
Main Prefault - Fault	X	X	X
Ramping Sequencer CT Magnetization		X	X
Impedance			X
Prefault - Fault with MTT		X	X
Prefault - Fault with MTT and reference curves		X ¹⁾	X ¹⁾

1) Requires SVERKER Viewer Licence

Included accessories for all above

Test cable set standard	GA-00030
Earth (ground) cable	GA-00200
Cable set 900 V	GA-00036
Flight case with wheels	GD-00185

Optional accessories

SVERKER Viewer PC Software	CR-8101X
-----------------------------------	----------

When ordering to an existing SVERKER 900, Please specify the serial number.
The license key is individually related to the serial number of the SVERKER 900. The test files need to be licensed to be able to open with SVERKER Viewer. The SVERKER Viewer software itself, can be installed on unlimited number of PC's.

Flight case	GD-00182
Low current adapter	CR-90010
Calibration box	CR-91010

Postal address

Megger Sweden AB
Box 724
SE-182 17 Danderyd
SWEDEN

T +46 8 510 195 00
E seinfo@megger.com

SVERKER-900_DS_en_V16a

ZI-CR01E • Doc. CR0271QE • 2020
Subject to change without notice
Megger Sweden AB
Registered to ISO 9001 and 14001
The word 'Megger' is a registered trademark

www.megger.com

Megger[®]